

# AMP RESEARCH Power Step



**5YR**  
WARRANTY

INTEGRATED  
**LED**  
LIGHT KIT  
STANDARD

- High-strength, die-cast aluminum linkage arms – anodized and Teflon® coated to resist corrosion
- Precision, zero-maintenance stainless-steel pivot pins
- Extruded aluminum steps with a textured powder-coat finish for maximum grip and durability
- 600 lb load capacity (each side)
- Weatherproof, OEM-quality electric motors, wiring harness and sealed connectors
- Pressure-sensitive, pinch-proof safety technology
- 5-year/60,000 mile warranty



Innovation  
In Motion.™

**OPEN DOOR. STEP ON BOARD.** AMP Research Power Step automatically deploys for easy stepping in and out of your high-riding truck. When doors close, this power-operated running board retracts safely out of sight with no loss of ground clearance. The AMP Research Power Step is built to perform in severe driving conditions and is backed by a 5-year/60,000 mile warranty.



**DOOR OPEN** - Automatically extends down when doors open. Full-length running boards provide easy entry and exit for both front and rear doors.



**DOOR CLOSED** - Retracts safely under the vehicle with no loss of ground clearance.



Heavy-duty, weatherproof motor and drive system with anti-pinch technology for safe, year-round dependability.

1-888-983-2206 | [amp-research.com](http://amp-research.com)



VEHICLE APPLICATION	MODEL YEAR	PART N°	NOTE
<b>GM</b>			
Chevy Silverado/GMC Sierra Extended Cab	2007 – 2010	75123-01A	
Chevy Silverado/GMC Sierra Crew Cab	2007 – 2010	75126-01A	
Chevy Silverado/GMC Sierra Extended Cab/Crew Cab	1999 – 2007 <i>Classic</i>	75113-01A	(1)
Chevy Tahoe/GMC Yukon	2001 – 2006	75114-01A	(1)
Chevy Tahoe/GMC Yukon	2007 – 2010	75124-01A	
Chevy Suburban/GMC Yukon XL	2001 – 2006	75115-01A	(1)
Chevy Suburban/GMC Yukon XL	2007 – 2010	75125-01A	
Chevy Avalanche (with cladding)	2000 – 2006	75114-01A	(1)
Chevy Avalanche (w/o cladding)	2000 – 2006	75115-01A	(1)
Chevy Avalanche	2007 – 2010	75125-01A	
Cadillac Escalade	2002 – 2006	75114-01A	(1)
Cadillac Escalade	2007 – 2010	75124-01A	
Cadillac Escalade EXT/ESV	2002 – 2006	75115-01A	(1)
Cadillac Escalade EXT/ESV	2007 – 2010	75125-01A	
HUMMER® H2/H2 SUT	2003 – 2010	75107-01A	
HUMMER® H3/H3T	2005 – 2010	75116-01A	
(1) <b>Diodes required</b> – GM vehicle model years 1999-2002, require four (4) additional diodes that are not included in the standard parts kit. When ordering please specify the vehicle model year so that diodes can be included. Additional diodes (Part # 401.90) may be ordered at no charge and shipped UPS Ground by calling 1-800-983-2206.			
<b>DODGE</b>			
Dodge Ram Quad Cab 1500	2009 – 2010	75143-01A	<b>NEW!</b>
Dodge Ram Quad Cab 1500	2002 – 2008	75101-01A	
Dodge Ram Quad Cab 2500/3500	2003 – 2009	75101-01A	
Dodge Ram Crew Cab 1500	2009 – 2010	75138-01A	<b>NEW!</b>
Dodge Ram Crew Cab & Mega Cab, 2500/3500	2010 +	75138-01A	<b>NEW!</b>
Dodge Ram Mega Cab 1500/2500/3500	2006 – 2009	75118-01A	
<b>FORD</b>			
Ford F-150 Super Cab/Super Crew	2009 – 2010	75141-01A	
Ford F-150 Super Cab/Super Crew/Lincoln Mark LT	2004 – 2008	75105-01A	
Ford F-150 Super Crew (Heritage)	1999 – 2004	75111-01A	
Ford Super Duty F-250/F-350/F-450 Regular Cab/Super Cab/Crew Cab	2002–2003 / 2008 – 2011	75134-01A	<b>NEW!</b>
Ford Super Duty F-250/F-350/F-450 Regular Cab/Super Cab/Crew Cab	1999 – 2001 / 2004 – 2007	75104-01A	(2)
Ford Excursion	2000 – 2001 / 2004-2005	75104-01A	(2)
Ford Excursion	2002 – 2003	75134-01A	(2)
(2) <b>Diodes required</b> – 2004-2007 Ford Super Duty trucks <u>without</u> remote keyless plus 1999 and older Super Duty trucks <u>with</u> remote keyless entry require four (4) additional diodes that are not included in the standard parts kit – When ordering please specify the vehicle model year so that the diodes can be included. If needed, additional diodes (Part # 401.90) may be ordered at no charge and shipped UPS Ground by calling 1-800-983-2206.			
<b>JEEP®</b>			
Jeep Wrangler Unlimited (JK)	2007 – 2010	75122-01A	<b>NEW!</b> 4-door only
<b>NISSAN</b>			
Nissan Titan Crew Cab/King Cab	2004 – 2010	75110-01A	
Nissan Armada/Infiniti QX56	2004 – 2010	75110-01A	
<b>TOYOTA</b>			
Toyota Tundra CrewMax/Double Cab/Sequoia	2007 – 2010	75137-01A	
Toyota Tacoma Double Cab	2005 – 2010	75142-01A	<b>NEW!</b>
<b>POWER STEP EXTRAS</b>		<b>PART N°</b>	<b>NOTE</b>
Power Step Extension Arm Kit – Includes four (4) arms. Provides 2-inch extra drop for lifted trucks.		75130-01A	Ford Super Duty and Dodge Ram only.
Power Step LED Light Kit – Includes four (4) LED lamps and wire harness.		75131-01A	Compatible with new style controller only.
Power Step Diode Kit – Includes four (4) single diodes per kit. (Required for some applications.)		401.90	See GM and Ford application notes above.