

AMP RESEARCH Bed X-Tender™



- Durable Black or Silver powder coat finish
- Lightweight, super strong 6063 T6 aluminum tubes
- Rugged glass-reinforced nylon composite uprights



HAUL MORE. AMP Research Bed X-Tender™ instantly adds up to two feet of length to your truck bed. Made of 6063 T6 aluminum, this proven design is lightweight, yet tough enough to use as a bench. Whatever you load in your truck, keep it secure with an the original Bed X-Tender™, designed and manufactured in the USA and backed by a 3-year/36,000 mile warranty.



EASY TO USE – Lower the tailgate and flip Bed X-Tender™ outward to gain an extra 2-feet of enclosed bed length – Flip forward and close the tailgate to create an enclosed area to secure tools, supplies, camping gear or shopping bags.

APPLICATION		Size/Type ▶	GM Truck Specific Kit	Large Truck Universal	Small Truck Universal	Small Truck MotoXTender
Part Number - Silver Finish ▶			74505-00A	74504-00A	74501-00A	74509-00A
Part Number - Black Finish ▶			74505-01A	74504-01A	74501-01A	74509-01A
CHEVROLET / GMC						
Colorado / Canyon - Short bed - 2004 – 2010	<i>Requires extra mounting kit - 74600-01A</i>				●	●
Silverado / Sierra - Stepside bed - 2007 – 2010		●				
Silverado / Sierra - Standard bed - 2007 – 2010		●				
Silverado / Sierra - Stepside bed - up to 2007 Classic				●		
Silverado / Sierra - Standard bed - up to 2007 Classic				●		
S10 - Stepside bed - 1996 – 2004	<i>Requires extra mounting kit - 74601-01A</i>				●	
S10 - Standard bed - 1996 – 2004	<i>Requires extra mounting kit - 74601-01A</i>				●	
C/K Pickup - Stepside bed - 1988 – 2000				●		
C/K Pickup - Standard bed - 1988 – 2000				●		
DODGE						
Dakota - Standard bed - 1987 – 2010				●		●
Ram - Stepside bed - all model years				●		
Ram - Standard bed - 1982 – 2010				●		
FORD						
F-150 - Flairside bed - 1997 – 2010				●		
F-150 - Standard bed - 2004 – 2010	<i>Optional no-drill bracket - 74602-01A</i>			●		
Lincoln Mark LT - Standard bed - 2006 – 2010	<i>Optional no-drill bracket - 74602-01A</i>			●		
F-150 - Standard bed - 1997 to 2004 Heritage Edition				●		
F-250 / F-350 Super Duty - Standard bed - 2008 – 2010	<i>Optional no-drill bracket - 74602-01A</i>			●		
F-250 / F-350 Super Duty - Standard bed - 1997 – 2007				●		
Ranger - Flairside bed - 1982 – 2010				●		
Ranger - Standard bed - 1982 – 2010					●	●
Explorer Sport Trac - 2001 – 2010				●		
ISUZU						
Hombre - Standard bed - 2006 – 2008					●	●
MAZDA						
B-Series - Standard bed - 1994 – 2010	<i>Requires extra mounting kit - 74601-01A</i>				●	●
MITSUBISHI						
Raider - Standard bed - 2006 – 2008					●	●
NISSAN						
Frontier - Standard bed - 1998 – 2010					●	●
Titan - Standard bed - 2004 – 2010				●		
Pickup - Standard bed - all earlier models	<i>Requires extra mounting kit - 74601-01A</i>				●	
TOYOTA						
Tundra - 2007 – 2010				●		
Tundra - 2000 – 2006	<i>Requires extra latch kit - 74603-01A</i>				●	●
Tundra D-Cab - 2000 – 2006				●		
Tacoma - 2005 – 2010	<i>Requires extra latch kit - 74603-01A</i>				●	●
Tacoma - 1995 – 2004					●	●
T-100 Pickup - Standard bed - 1993 – 1998	<i>Requires extra latch kit - 74603-01A</i>				●	
Pickup - Stepside bed - 1984 – 1994	<i>Requires extra mounting kit - 74601-01A</i>				●	
Pickup - Standard bed 1984 – 1994	<i>Requires extra mounting kit - 74601-01A</i>				●	
BED X-TENDER EXTRAS						
Quick Latch Mounting Bracket Kit - 74605-01A	<i>Optional kit compatible with all models</i>		○	○	○	○
Standard Mounting Bracket Kit - 74604-01A	<i>Included with all models</i>		○	○	○	○