



TOW PRO

ADVANCED TOWING SOLUTIONS
by Ridetech



AUTOMATIC LOAD LEVELING SYSTEMS

ridetech

Air Ride Technologies
www.ridetech.com
812-481-4751

TOWPRO advanced towing system

Load leveling systems made easy...

RideTech is the industry leader in performance air suspension systems for all types of performance vehicles. Now RideTech has developed an advanced engineered product line offering a simple yet effective load leveling system designed to maintain your trucks ride height while providing an improved ride quality. The TowPRO systems include a vehicle specific kit, engineered to bolt into your application without any modifications. **visit www.ridetech.com/towpro** for additional info.

Features

- TowPRO systems include a self leveling compressor system that automatically maintains vehicle ride height.
- With an integrated ECU, the Smart Sensor can intelligently trigger a compressor to inflate the system, or trigger a valve to deflate the system to constantly maintain vehicle level regardless of load changes without undue stress on the compressor system.
- The control panel adds a manual inflate and deflate, along with a power button to turn the system on and off.
- TowPRO air helper springs provide improved load support through the use of self adjusting air pressure that compensates for changing loads.
- TowPRO systems include industry leading Mono-tube shock absorbers designed for exact fit of the OEM shock absorbers. With increased towing capacity the OEM shock valving is insufficient due to the heavy loads.





Application	Year	Tow Pro AirSprings Shocks & Comp. kit	Front Shock Upgrade
CHEVY/ GMC		\$1500	\$350 Pair
Silverado C1500 2wd	1999-2006 2007 classic	81214001	NA
Silverado K1500 4wd	1999-2006 2007 Classic	81214002	81211001
Silverado C2500HD 2WD	2001-2010	81214003	81211002
Silverado K2500HD 4WD	2001-2010	81214003	81211002
Silverado C3500 2WD	2001-2010	81214003	81211002
Silverado K3500 4WD	2001-2010	81214003	81211002
Silverado C2500HD 2WD	2011-2014	81214004	81211003
Silverado C3500HD 2WD	2011-2014	81214004	81211003
Silverado K2500HD 4WD	2011-2014	81214004	81211003
Silverado K3500HD 4WD	2011-2014	81214004	81211003
Silverado C1500 2WD	2007-2014	81214005	NA
Silverado K1500 4WD	2007-2014	81214005	NA
Silverado C1500/2500/3500	1988-1998	81214006	NA
G1500 Express Van	2003-2012	81214007	
DODGE		\$1500	\$350 Pair
Ram 1500 2WD	1994-2001	81234001	NA
Ram 1500 4WD	1994-2001	81234001	81231001
Ram 2500 2WD	1994-2002	81234002	NA
Ram 2500 4WD	1994-2002	81234002	81231002
Ram 3500 2WD	1994-2002	81234002	NA
Ram 3500 4WD	1994-2002	81234002	81231002
Ram 1500 2WD	2006-2008	81234003	NA
Ram 1500 4WD	2002-2005	81234003	NA
Ram 1500 4WD	2006-2008	81234003	NA
Ram 1500 4WD	2002-2005	81234003	81231003
Ram 1500 MegaCab 4WD	2006-2008	81234004	81231002
Ram 2500 2WD	2003-2012	81234004	NA
Ram 2500 4WD	2003-2012	81234004	81231002
Ram 3500 2WD	2003-2012	81234004	NA
Ram 3500 4WD	2003-2012	81234004	81231002
RAM 1500 2WD	2009-2014	81234005	NA
RAM 1500 4WD	2009-2012	81234005	NA
RAM 2500 2WD	2013	81234006	NA
RAM 2500 4WD	2013	81234006	81231002
RAM 3500 2WD	2013-2014	81234006	NA
RAM 3500 4WD	2013-2014	81234006	81231002

Application	Year	Tow Pro AirSprings Shocks & Comp. kit	Front Shock Upgrade
DODGE		\$1500	\$350 Pair
RAM 2500 2WD	2014	81234007	NA
RAM 2500 4WD	2014	81234007	81231004
FORD		\$1500	\$350 Pair
F150 2WD	1997-2003 2004 Heritage	81224001	NA
F150 4WD	1997-2003 2004 Heritage	81224002	81221001
F250 Non SDuty 4WD	1997-2003	81224002	81221002
F250 Non SDuty 2WD	1997-2003	81224003	NA
F250 Super Duty 4WD	1999-2004	81224004	81221002
F350 Super Duty 4WD	1999-2004	81224004	81221002
F250 Super Duty 2WD	1999-2004	81224005	NA
F350 Super Duty 2WD	1999-2004	81224005	NA
Excursion 4WD	2000-2006	81224016	81221002
F150 2WD	2004-2008	81224006	NA
F150 4WD (not FX2)	2004-2008	81224007	NA
F250 4WD	2005-2007	81224008	81221003
F350 4WD	2005-2007	81224008	81221003
F250 2WD	2005-2007	81224009	NA
F350 2WD	2005-2007	81224009	NA
F250 4WD	2008-2010	81224010	81221003
F350 4WD	2008-2010	81224010	81221003
F250 4WD (GAS)	2011-2014	81224010	81221003
F350 4WD (GAS)	2011-2014	81224010	81221003
F250 2WD	2008-2010	81224011	NA
F250 2WD (GAS)	2011-2014	81224011	NA
F350 2WD	2008-2010	81224011	NA
F350 2WD (GAS)	2011-2014	81224011	NA
F150 2WD	2009-2014	81224012	NA
F150 4WD (not Raptor)	2009-2014	81224013	NA
F250 4WD (diesel)	2011-2014	81224014	81221003
F350 4WD (diesel)	2011-2014	81224014	81221003
F250 2WD (diesel)	2011-2014	81224015	NA
F350 2WD (diesel)	2011-2014	81224015	NA
TOYOTA		\$1500	\$350 Pair
Tundra	2007-2014	81244001	NA

812-481-4751





TOW *PRO*

ADVANCED TOWING SOLUTIONS

by Ridetech

RideTech
350 S St. Charles St.
Jasper IN 47546
www.ridetech.com
812-481-4751