

Now Available!

PRODUCTS FOR RVs



SunShade Display
9PDTS3

Indoor™/Outdoor™ Mat Display
9PDIOM2



Made in USA

Make	Chassis Model	SunShade Part #	All-Weather Mat Part #	FloorLiner™ Part #
Chevrolet	Express with mirror 1996–2020	TS0155K1	N/A	N/A
Chevrolet	Express without mirror 1996–2020	TS1331K1	N/A	N/A
Dodge	ProMaster 2014–2019	TS1047K1	W482	446481
Ford	Econoline with mirror	TS0092K1 (1992-2020)	W51 (1997-2020)	N/A
Ford	Econoline without mirror	TS1332K1 (1992-2020)	W51 (1997-2020)	N/A
Ford	Econoline E-Series 2003-2021	N/A	N/A	441411V
Ford	E350/E450 2015–2020	TS0092K1	W51	N/A
Ford	Transit 350/450 2015–2020	TS1168K1 (No sensor) TS1198K1 (With sensor)	W427	447391 (OTH) 449751V (Vinyl only)
Freightliner	M2 2004–2020	TS0265 (Daycab and Ext Cab) TS0265K1 (Daycab)	W509 (Uses retention kit for vinyl floor) W539 (Uses retention kit for carpet floor)	4416061V (2 pc. vinyl) 4415651 (2 pc. carpet)
Jayco	Seneca Freightliner 2004–2015	TS0265 TS0265K2	W509 (Uses retention kit for vinyl floor) W539 (Uses retention kit for carpet floor)	4416061V (2 pc. vinyl) 4415651 (2 pc. carpet)
Jayco	Seneca Freightliner S2RV 2016–2020	TS0265 TS0265K2	W509 (Uses retention kit for vinyl floor)	4416061V (2 pc.)
Mercedes-Benz	Sprinter with mirror 2007–2018	TS0116K1	W481	442491 (OTH) 442492 (Center aisle)
Mercedes-Benz	Sprinter without mirror 2007–2018	TS1333K1	W481	442491 (OTH) 442492 (Center aisle)
Mercedes-Benz	Sprinter 2019+	TS1253K1 (Large sensor) TS1262K1 (Small sensor)	W529 (Passenger van) W530 (Cargo van and crew van)	4415211 (Passenger) 4415221 (Cargo and crew; both are OTH)

Call for Pricing and Details: 800-943-9250

Email: Wholesale@WeatherTech.com

WeatherTechWholesale.com